



CA2891 (Near side LH)
Cast code **886**



CA2891R (Off side RH)
Cast code 885

These are fitted to a variety of vehicles **always** in the trailing position.